








# 주요부품 LIST

NO	PART NAME	Q'TY	REMARKS
1	두산인프라코어	1	DP158LC
2	BED FRAME	1	FUEL TANK
3	GENERATOR ASS'Y	1	380/220V
4	BELLOWS	1	
5	RADIATOR ASS'Y	1	
6	방진스크리밍 취부 홀	10	10-Ø18 Holes
7	GEN. CONTROL PANEL	1	









A

A

B

B

C

C

D

D

E

E

SYMBOL & ABBREVIATIONS

	START MOTOR		GEN. RUNNING AUX. RELAY		GEN. CIRCUIT BRACKER TRIP COIL
	WATER TEMPERATURE SWITCH (HIGH)		LUB. OIL PRESSURE SWITCH (LOW)		EMERGENCY STOP PUSH BUTTON
	WATER TEMPERATURE SENSING UNIT		OIL PRESSURE SENSING UNIT		OIL TEMPERATURE SENSING UNIT
	ALTERNATOR				

PROTECTION LAMP

☐ Fault

STATUS LAMP

☐ MANUAL MODE

☐ AUTO MODE

☐ RUNNING

☐ STOP

GEN. DISPLAY

x3

x3

ENGINE DISPLAY

PROTECTION

OVER VOLTAGE

UNDER VOLTAGE

OVER CURRENT

HIGH WATER TEMP.

LOW OIL PRESS.

HIGH OIL TEMP.

EMERGENCY STOP

OVER SPEED

FAIL TO START

LOW/HI BATT. VOLT.

(차단기 차단력)

